


WIRELESS
CONTROLLER

FOR P5 CONSOLE







User Manual

產品說明書

P203W/ P203BK



CH

① L1鍵

② SHARE鍵

③ 方向鍵

④ 喇叭

⑤ 左搖桿/L3

⑥ Home鍵

⑦ 觸摸屏/ 下壓鍵

⑧ R1鍵

⑨ Option鍵

⑩ 動作鍵/ □○△X

⑪ 右搖桿/R3

⑫ R2鍵

⑬ Turbo鍵

⑭ M1/ ○鍵

⑮ 復位按鍵孔

⑯ 3.5耳機插孔

⑰ Type c 充電口

⑱ RGB 指示燈

⑲ L2鍵

⑳ M2/ X鍵

EN

① L1 Button

② Share Button

③ Direction Button

④ Speaker

⑤ Left Joystick/L3

⑥ Home Button

⑦ Touch Screen/Downward Press Button

⑧ R1 Button

⑨ Option Button

⑩ Action Button/ □○△X

⑪ Right Joystick/R3

⑫ R2 Button

⑬ Turbo Button

⑭ M1 / ○ Button

⑮ Reset Button Hole

⑯ 3.5mm Headphone Jack

⑰ Type c Charging Port

⑱ RGB Indicator Light

⑲ L2 Button

⑳ M2/ X Button

產品特色

CH

1.該產品屬於P5 無線控制手柄，用於P5 主機各類遊戲的控制，使您在遊戲過程中體驗到身臨其境的感覺。

2.兼容P5 原裝手柄的所有按鍵，馬達對應功能，Touch 功能，音頻喇叭，立體聲耳麥插孔，Sensor 功能。

3.提供2個Mn鍵可設置Remap功能，有14個按鍵（↑、↓、←、→、□、○、△、X、L1、R1、L2、R2、L3、R3）

操作指引

1.連結說明

P5主機連結：開啟P5主機，手柄休眠狀態下，使用Type C-USB 線連結主機及完成配對，完成後按下Home鍵進行無線連結，拔掉線即可無線操作。

PC 電腦連結：手柄Type C-USB 線連結主機即可使用(PC端不支援震動)。

2.Remap 功能使用說明

Mn 鍵=M1、M2 鍵(初始值：M1默認○ 鍵，M2默認 X 鍵)可以設定Remap的按鍵：

↑、↓、←、→、△、○、□、X、L1、R1、L2、R2、L3、R3。(除方向鍵只能設置單個方向，其他功能鍵可同時設置多個功能到Mn鍵上)。



— 1 —

3.Remap 功能設定

步驟1：按住Mn 鍵，再按住Share 鍵，即進入設定模式。

步驟2：按下想設置的按鍵（可多鍵），再按下Mn 鍵，即設定完成並退出設定模式；

例如： 按住Mn 鍵，再按下Share 鍵，進入設定模式；
按下R1 鍵，再按M1 鍵，即設定完成並退出設定模式，此時M1 鍵和R1 鍵功能一致。

清除Mn鍵功能：
按住Mn 鍵，再按Share 鍵，再按Mn 鍵保存清除無功能。
(如需有功能再進行設定)

4.Turbo 功能

a.手動連發設置：(第一次) 任意按（△、○、□、X、L1、R1、L2、R2）一個或幾個動作鍵，再按Turbo 鍵，開啟手動連發功能；

b.自動連發設置：(第二次) 再次按下已開啟手動連發功能的動作鍵，並再按Turbo 鍵，開啟自動連發功能；

c.清除連發設置：(第三次) 在次按下已開啟自動連發功能的動作鍵，並再按Turbo 鍵，清除連發功能

產品參數

工作電壓：D C 3.5V-4.2V

工作電流：100mA±10mA 最大電流 < 300mA

休眠電流：30uA

充電口：Type C

內置離電池：600mAh

輸入充電電壓：D C 5V

充電電流：400mA

藍牙版本：4.0

傳輸距離：10M

內置功能：非對稱震動馬達，Touch，單音喇叭，立體聲耳麥插孔，Sensor功能

— 2 —

Features

EN

1. This is a P5 wireless controller, which is used to play various games on the P5 console, providing player an immersive feeling during the game.

2. Compatible with all buttons, motor corresponding function, Touch function, audio speakers, stereo headset jack, and Sensor function of the original P5 controller.

3. Provides 2 Mn keys to set the Remap function, with 14 buttons（↑、↓、←、→、□、○、△、X、L1、R1、L2、R2、L3、R3）

Operation Instructions

1.Connections

P5 Connection: Turn on the P5 console. When the controller is in sleep mode, use the Type C-USB cable to connect to the console to pairing.
After successful pairing, press the home button to connect wirelessly. Unplug the cable to control wirelessly.

PC Connection: Use the Type C-USB cable to connect the controller and console to use (PC does not support vibration function).

2.Remap Function

Mn key = M1, M2 key (initial value: M1 defaults to ○ key, M2 defaults to x key) You can set the Remap keys:
↑、↓、←、→、△、○、□、X、L1、R1、L2、R2、L3、R3. (Except for the direction keys, which can only set a single direction, other function keys can set multiple functions to the Mn key at the same time).



— 3 —

3Remap function setting

Step 1: Press and hold the Mn key, then press the SHARE Button to enter the setting mode.

Step 2: Press the button you want to set (multiple keys are allowed), then press the Mn key, the setting is completed and the setting mode is exited.

For example:
Press and hold the M1, then the SHARE Button to enter the setting mode; press the R1, then press the M1, the setting is completed and the setting mode is exited; at this time, the functions of the M1 and the R1 are the same.

Clear the Mn key function:
Press and hold the Mn key, then press the SHARE Button, and press the Mn key again to save and clear the function. (If you need a function, set it again)

4 Turbo Function

a. Manual burst setting: (First time) Press any one or more action buttons（△、○、□、X、L1、R1、L2、R2），and then press the TURBO key to turn on the manual burst function;

b. Automatic burst setting: (Second time) Press again the action button that has the manual burst function turned on, and then press the TURBO key to turn on the automatic burst function;

c. Clear burst setting: (Third time) Press again the action button that has the automatic burst function turned on, and then press the TURBO key to clear the burst function.

Product Parameters

Working voltage: DC 3.5V-4.2V

Working current: 100mA±10mA Maximum current <300mA

Sleep current:30uA

Interface: Type C

Built-in lithium battery: 600mAh

Input charging voltage: DC 5V

Charging current: 400mA

Bluetooth version: 4.0

Transmission distance: 10M

Built-in functions: Asymmetric vibration motor, Touch, mono speaker, stereo headset jack, Sensor function

— 4 —

— 5 —

